




# Connection issue (Between Bluetooth or Printer with Tablet)



## Printer Connection Error



# Connection issue (Between Bluetooth or Printer with Tablet)

## Instructions

Issue Date  
6/28/23


1

2 min

**TABLET  
MANUAL**

### How to Pair

(New tablet with LP2824Plus printer and Bluetooth dongle)



The image shows a white LP2824Plus printer, a blue Bluetooth dongle, and a tablet displaying a colorful abstract pattern. The printer is on the left, the dongle is in the middle, and the tablet is on the right. The background is white.

**AFC**  
Franchise Corp.

Confidential

LP2824Plus printer with Bluetooth dongle

1. You can power cycle Bluetooth dongle.
2. Try to unpair and repair the BT in the tablet setting.

Please see instructions of pairing tablet with printer (LP2824)


2-1

2 min

**TABLET  
MANUAL**

### How to Pair

(New tablet with ZD410)



The image shows a grey ZD410 printer and a tablet displaying a colorful abstract pattern. The printer is on the left and the tablet is on the right. The background is white.

**AFC**  
Franchise Corp.

Confidential



ZD410

1. Try to unpair and repair the printer with the tablet in the tablet setting.

Please see instructions of pairing tablet with printer (ZD410)

## 2-2

5 sec


TABLET MANUAL		Printer Calibration & Factory Reset Zebra	
		Instructions	Issue Date 6/28/23
1		<b>Media Calibration (ZD410)</b>	<ol style="list-style-type: none"> <li>1. Press and hold PAUSE and CANCEL buttons for about 2-3 seconds OR until printer starts dispensing labels.</li> <li>2. Two blank labels will dispense.</li> </ol>
2-1		<b>Factory reset (ZD410)</b>	<ol style="list-style-type: none"> <li>1. Turn off the printer</li> <li>2. Press and hold PAUSE (  ) and FEED ( ) buttons while turning on printer.</li> <li>3. Release when indicator light turns on.</li> </ol>

If pairing is not accepted or rejected OR printer is not showing on the available devices list, please reset the ZD410 printer through reset button and factory reset function.

Please see instructions of Printer Calibration & Factory Reset Zebra 2-1,2,3

## 2-3

30 sec



Pressing feed button for about 5-6 seconds on the ZD410 printer will also force the printer's Bluetooth to be in pairing mode.

If the printer is in pairing mode, the data light will be on or flashing green.

Please see instructions of pairing tablet with printer (ZD410)